

PROJECT 8

FIT A WEATHER GUARD ON A DOOR

YOU'LL NEED

Wooden weather guard, pencil, wood saw, spirit level, cordless drill, wood drill bit, varnish/enamel paint, sandpaper, wood glue, wood screws of correct length, screwdriver

STEP 1

Place the weather guard against the door and measure and mark the correct width with the door closed. Mark the cutting line and saw off the excess.



Striped doormat R130 and watering can R99, both @home

STEP 2

Keep the weather guard in position at the bottom of the door and use the spirit level to ensure it is level before you start drilling. Drill the holes required.

STEP 3

Sand and varnish or paint the weather guard and leave to dry. Ensure the screws are the correct length; they must be driven at least 15 mm into the door. Lightly sand the bottom edge of the door where the guard will fit so the glue will stick well. Also sand the matching side of the weather guard. Apply enough glue to it and fix it to the door. Use a screwdriver to secure with the screws.

