

PROJECT 2 Install a lock in a cupboard door

BEFORE



WHAT YOU NEED

20 mm flat drill bit, plastic lock and key, screws, screwdriver, 2 mm drill bit, electric drill



STEP 1

Measure exactly where the keyhole will be and mark the place with a pencil.



STEP 2

Use the Bosch drill with 20 mm flat drill bit to drill a neat hole.



STEP 3

Position the lock over the hole at the back of the door so the key is in the correct position. Use a pencil to mark where the screws will go. Drill pilot holes with the 2 mm drill bit and screw the lock in place. Insert the keyhole cover in the hole.

Laundry bin **R129**, @home.



TIP: USE MASKING TAPE TO STICK AN OPEN ENVELOPE BELOW THE POINT WHERE YOU ARE DRILLING TO CATCH ALL THE DUST.