

PROJECT 1 Tidy away loose cables and wires

YOU'LL NEED

Bosch electric drill, Bosch 80 mm hole saw, 8 m measuring tape, glue gun, glue sticks

BEFORE



STEP 1

Measure and mark a point 100 mm from the wall on the underside of the desk where the cable-tidy hole will be drilled.



STEP 2

Drill a hole with the 80 mm hole saw. Push the cables through the hole.



Black frame **R160, Woolworths**. Fabric-covered letters of the alphabet **R29,99 each** and pink metal bucket **R99,95, Wetherlys**. Black woven storage basket **R99,99, Mr Price Home**.

STEP 3

Use the glue gun to stick down the wires under the desk.

