

**BEFORE**



## YOU'LL NEED

Spirit level, 300 mm shelf brackets, pencil, Bosch electric drill, 6 mm masonry bit and M6 nail-in anchors with round-head screws, 15 mm chipboard screws

### STEP 1

Mark the position of the shelf. Use the spirit level to make sure it will be horizontal.



### STEP 2

Place the brackets against the wall and mark the holes with a pencil.

On the shelf: Black glass vase **R699, Wetherlys**. Black glass tealight holder **R19,95, Woolworths**. Brown woven utility basket **R59,99, Mr Price Home**. Globe **R495, Coricraft**. On the floor: Pink woven bin **R39,99**, brown woven utility basket **R59,99**, black woven storage basket **R99,99, Mr Price Home**. Black and white storage boxes **R69,95** for small and **R89,95** for large, **Woolworths**. Silver glitter vase **R19, Sheet Street**.



### STEP 3

Drill holes in the wall and insert anchors.



### STEP 4

Attach the brackets to the wall with round-head screws. Mark bracket holes on the underside of the shelf, drill and screw the shelf to the bracket with chipboard screws.

**TIP:** FOR SAFETY'S SAKE USE A PIPE DETECTOR TO CHECK THE WALL FOR ELECTRICAL CABLES BEFORE DRILLING HOLES FOR THE SHELF.