

Paint an interior wall in an accent colour

PROJECT 2

BEFORE



YOU'LL NEED

Masking tape, Crown plaster primer, Dulux gloss enamel (Golden Yellow), Academy mock mohair roller, 50 mm paintbrush

STEP 1

Mask the edges of the wall to prevent paint seepage.



STEP 2

Apply the primer with a roller and leave to dry.



Side table **R199,99** and yellow canvas scatter cushions **R69,99** each, **Mr Price Home**. Lamp **R599**, black glass candleholder **R59,95**, black candle **R17,95** and frame **R49,95**, **Woolworths**. Silver vase **R395**, **Coricraft**. White mug **R49,99** for **four**, **Clicks**. Black and white Devan Waves duvet set **R199,99**, **Sheet Street**.

STEP 3

Apply the accent colour with the roller, switching to the paintbrush for awkward corners.



TIP: BEFORE APPLYING PAINT, THOROUGHLY CLEAN THE SURFACE AND REPAIR ANY CRACKS TO ENSURE EVEN APPLICATION.