


REPLACING A SHOWER HEAD

PROJECT RATING:
EASY



STEP 1

- Turn off the shower tap.



STEP 2

- Unscrew the old shower head by turning in a clockwise direction.
- Wait for the shower to run dry.



STEP 3

- Use an adjustable wrench or locking pliers to carefully unscrew the arm from the wall by turning in an anti-clockwise direction.



STEP 4

- Thread plumber's tape onto the thread of the new shower arm in a clockwise direction.
This will prevent leaks.



STEP 5

- Screw the new shower head onto the plumber's tape on the new shower arm's thread by turning in a clockwise direction.



STEP 7

- Turn on the water supply and test your new shower head.

