

Install a new showerhead

PROJECT 4

You'll need

A shower head, extension, shifting spanner, steel brush, Teflon tape

Fig & Cassis liquid soap R65 and Fig & Cassis hand and body lotion R65, @home. Glycerine soaps R29 each, Loads of Living.

STEP 1

Make sure the threads on the pipes are clean. Wrap Teflon tape around the thread of the water pipe – two layers will be enough. The tape will prevent leakage.



STEP 2

Screw the water pipe securely to the extension pipe and make sure it is at the correct angle for the water to spurt downwards.



STEP 3

Screw the shower rose securely to the extension pipe.



TIP:

BEFORE YOU START, COVER THE SHOWER DRAIN TO PREVENT ANYTHING GETTING STUCK IN THE TRAP.